

TableHockey ROD & DRIVE ASSEMBLY

- **I.** After mounting legs, handle, clear clamps, etc., slide one team of 6 rods through the frame end holes as pictured above. The right wing rods are longer and have red tape at ends (red = right). Place other team of rods the same way from the other end.
- 2. Slide the 10 player glides and the 2 smaller goalie glides onto the stainless rod pins as shown.
- **3.** Attach the 10 player springsets to rod pins and tighten setscrews til just snug using larger tool, then snap each T-shaped bushing into the large glide hole.
- **4.** Attach the 2 goalie springsets by first putting the T-shaped bushing into glide hole, then aligning rod bushing to pin and tightening setscrew til just snug.
- **5.** Position all player rod assemblies at center ice, then flip game over onto its legs. Place each color team on the ice at its proper slot and mount each player and goalie to its glide and spring as shown in GAME CAREVIDEO. A good practice is to first push player peg fully into bushing, then remove player, then again push peg in slightly less deep. If player feels tight in its slot, adjust by pulling up sightly on player. If player blade is high, loosen setscrew, push peg deeper, then retighten.





